

## HEADLIGHT

### INSTRUCTIONS FOR RECTANGULAR KIT

1. Before removing old lights, park your GMC so the headlights will shine on a wall or other surface so you can mark the center of light beam on high beam. This is so when new lights are installed, you can use these marked spots to adjust the new lights. You may want to fine tune the adjustment but this will get lights in approximate adjustment.
2. Remove light bezels, bulbs adjusting screws and drill out rivets that hold the two plastic nuts that hold adjusting screws. (Leave spring in place that holds light bucket.)
3. Install aluminum brackets to hold new adjusting screws with pop rivet from backside included. The "U" shaped bracket is mounted at top in holes, where old adjusting screw was removed. Install open side of "U" bracket facing down. Remove screw from plastic adjusting nut and install plastic adjusting nut from bottom side.
4. Install "Z" shaped bracket on side in holes where adjusting nut was removed. Remove plastic nut from one of the new adjusting screws and install plastic nut in this bracket from the bottom side before installation of brackets.
5. Install bulb in bucket and stainless steel ring. Hook spring in bucket, two adjusting screws in slots of bucket and screw into plastic nuts. Adjust screws until light matches spot on wall. (If side adjusting screw is too long, use old screw or cut off new one.
6. Installation of Fiberglass Bezel.
  - a. Drill holes in bezel and counter sink holes for the screw.
  - b. Now remove bezel and paint color of your choice and reinstall.

### RECTANGULAR LIGHTS, F.J.

